


deli得力

针式打印机 使用说明书 USER'S MANUAL

打印机驱动网
www.dyjqd.com



得力集团有限公司

DELI GROUP CO., LTD.

地址:浙江宁海得力工业园

Add:Deli Industry Zone, Ninghai County,
Zhejiang Province,China

全国服务热线: 400-185-0555

传真(Fax): 0574-65273660

Http://www.nbdeli.com

MADE IN CHINA



版本: 1.0

日期: 2015年7月

ARTICLE NO.: DL-630K、DE-630K

货号	DL-630K、DE-630K	货名	针式打印机	零件名称	说明书
----	-----------------	----	-------	------	-----

1. 开箱和检查

打开纸箱，对照下图检查箱内部件和附件是否齐全




光盘



联机电缆



载纸板



色带



说明书



保修卡



合格证




打印机

※装箱清单可能根据用户订制需要存在差异。


2. 拆除保护材料

通电工作前，按图示拆除保护材料。




3. 打印机部件

1. 前盖：保护打印头及其它内部部件并降低噪音；
2. 载纸板：用于放置单页纸，以使其出入；
3. 导纸板：调整摩擦式进纸（前进纸）的边缘位置，导向纸张正确送入；
4. 打印头：打印针及其驱动部分组成；
5. 送纸调杆：该调杆有两个位置，“”为链式纸，“”为单页纸；
6. 电源开关：电源接通或断开；
7. 控制面板：显示打印机状态，可对打印机功能进行多种简易操作；
8. 色带：内装打印色带芯；
9. 色带导架：固定色带芯；
10. 电源线：连接打印机和电源；
11. 链轮：控制链式纸的传动、左右调整位置、锁定；
12. 接口：连接计算机与打印机。




4. 安装色带


1. 装上阵纸板。



2. 拉开前盖。




3. 装入色带：按次序将标识①、②的卡位安装于机架上，轻按色带，使其安装到位。




.3.

4. 拔出卡在色带上的色带导架。



5. 将打印头移至正中间，把色带导架上的卡位安装到打印头罩的对应卡位上，顺时针转动色带上的旋钮，来回移动打印头，确保色带已被拉紧。




.4.

货号	DL-630K、DE-630K	货名	针式打印机	零件名称	说明书
----	-----------------	----	-------	------	-----


5. 连接电源

1. 使电源开关处于关闭状态，将打印机电源线插头接到墙上的电源插座上。




6. 打印机与主机连接

1. 使用USB电缆：电缆的一端连接到打印机背面USB插座上，另一端接到计算机。




2. 将36芯插头与打印机相连，25芯D型插头连接到计算机即可。



7. 安装打印机驱动程序

1. 适用于Windows 2000 / XP / Vista / 7 / 8

打开计算机、打印机电源，若出现“找到新硬件向导”窗口，请点击窗口中的“取消”按键将其中断，把驱动光盘放入光驱：



- 在自动弹出（或双击光盘中的“autorun.exe”文件打开）的界面中，点“驱动安装”；
- 在“得力打印机驱动安装步骤1”界面，点“下一步”；
- 选择打印机型号，点“下一步”；
- 打印机使用USB电缆连接线的，驱动软件会自动识别USB端口，直接点“下一步”即可；否则，请手动选择端口，再点“下一步”；
- 确认“机型”、“端口”，点“完成”按键，出现“正在安装打印机驱动”字样，稍等片刻，出现“OK”对话框后，点“确定”按键，驱动安装完毕。


⚠ 注意：使用Window 95/98时，需手动设置安装驱动程序。

.6.


货号	DL-630K、DE-630K	货名	针式打印机	零件名称	说明书
----	-----------------	----	-------	------	-----

8.使用链式打印纸


1.将送纸调杆拨至“链”位置。



2.拨动链轮上的锁杆，释放链轮。




3.根据打印起始边移动左侧（从机背视图方向）的链轮，按纸张的宽度向右移动右侧的链轮。




.7.


4.将链式纸的纸孔套在纸夹的针轮上，注意纸孔必须与针轮一一对应、纸张没褶皱；合上左/右纸夹。



5.下按锁杆，锁定链轮。




6.链式纸放于打印机背后，纸叠高度不得高于链轮。




.8.

9.使用单页打印纸

1.将送纸调杆拨至“□”位置。



2.根据纸张宽度移动导纸板到合适的位置，使纸张的打印面朝上，左边对齐导纸板向前送纸。



10.备注

详细的操作描述，请查阅随机光盘中的《操作手册》。

本产品符合GB21521-2014《打印机、传真机能效限定值及能效等级》一级能效等级最高要求；符合国家《电子信息产品污染控制管理办法》的要求。有关物品物质状态，请详见光盘内附的《操作手册》说明。

产品与电网电源的断开装置：拔掉电源线插头能彻底切断产品与电源电网的连接。



中华人民共和国境内销售的电子信息产品必须标识此标志，标志内的数字代表在正常使用状态下的产品的环保使用期限。


.9.

1.Unpacking

Open the package and check whether the following items are included:




CD



USB Cable



Sheet Feeder



Ribbon Cartridge



User's manual



Warranty Card



Qualified Certificate





Printer

※ The packing list may be different for different customers.

2.Remove the protection materials


Before the printer is powered on, remove the protection materials from the printer as shown below.



.10.

3. Identify the printer components


1. Front Cover : Protects the Print Head and other parts inside, and reduces noise.
2. Sheet Feeder : Supports the cut sheet so as to ensure the paper in and out easily.
3. Paper Guides : Adjusts the position of a cut sheet.
4. Print Head : 24-pin printing mechanism.
5. Paper Path Lever : Two positions:  = continuous forms;  = single sheet paper
6. Power Switch : Powers the printer ON or OFF.
7. Control Panel : Shows printer status, for printer setup.
8. Ribbon Cartridge : Holds inked Ribbon in it.
9. Ribbon Guide : Guides Ribbon installation on the Print Head.
10. Power Cord : Connects the printer and power socket.
11. Tractors : For feeding and adjustment of continuous forms.
12. Interface : Connects interface cable from the host.




.11.

4. Install the ribbon


1. Install the Sheet Feeder.



2. Open the Front Cover.




3. Tilt the Ribbon Cartridge a bit and match it to the positions ① and ② on both ends. Then slightly press the Ribbon Cartridge down to hold it in the locking positions.




.12.

4. Take out the Ribbon Guide from the Ribbon Cartridge.




5. Move the print head to the middle. Mount the Ribbon Guide onto the Print Head. Then turn the Ribbon Knob in clockwise direction to tighten the ribbon fabric. Move the Print Head left and right to make sure the ribbon fabric is taut.



.13.

5. Connect the Mains Power


1. Switch off the power before connecting the power cord to the power socket.



Note: Wait for 5 seconds before reapply the power to the printer, to avoid damaging the printer. Please disconnect the power cord if the printer will not be used for a long time.


6. Connect the Interface Cable

1. USB interface is the standard configuration. Connect one plug of the cable to the USB interface located at the rear of the printer, while the other plug should be connected to PC.




2. Connect the 36-pin plug to the printer, while the 25-pin plug should be connected to PC.

Note: This is option



Parallel interface




.14.

7. Install the driver

1. Install the driver for Windows 2000/XP/Vista/Win7/Win8

Insert the CD to your PC, following the plug messages to complete the driver installation.




- a. Click "driver installation" in the prompted interface.
- b. Click "next" in the "Printer driver setup step 1" interface.
- c. Click "next" after selecting the printer model name.
- d. If the printer is connecting to PC by USB cable, USB port can be recognized by the driver automatically, please directly click "next". Otherwise, manually select the installation port, and then click "next".
- e. Click "finish" after checking the printer model and installation port. "Printer driver is being installed" will be displayed. Several seconds later, when "OK" is prompted, please click on it to finish the driver installation.

 Note: When using Windows 95/98, you need to install the drivers manually set.


.15.

8. Handle Continuous Forms (Fanfold)


1. Slide the Paper Path Lever to the "E" position.



2. To set the desired left margin and form width, disengage the Tractor Locks to allow free movement of the Tractors.




3. When the left margin is set, tighten the Left Lock (viewed from rear). Move the Right Tractors to the desired paper width.




.16.


4. Fit the first 3 paper holes onto the Left Tractor Pins. Close the Left Tractor Door. In the same way, install the paper on the right tractor.



5. Ensure the paper is flat and smooth before tightening the Tractor Lock.




6. Pile a stack of fanfold to the rear, at a height below the Tractors.




.17.

9. Handle Cut Sheet

1. Slide the Paper Path Lever to the “□” position.



2. Slide the Paper Guide to set the desired left margin. Manually insert a piece of cut sheet with printing side facing upward and left edge aligning to the Paper Guide, into the slot above the Sheet Feeder.



.18.