





How to upgrade my DVD-ROM drive?

This manual shows you how to
upgrade your drive with the
Philips DVD-ROM Upgrade tool.

Philips Consumer Electronics
Version 06

PHILIPS

<p>1 Start the Upgrade Tool you downloaded. Click "OK"</p>	 <p>The 'Flash Tool' dialog box has a blue title bar with a red close button. It contains a yellow warning icon and four numbered instructions: 1. Please remove any media from the device. 2. Please DO NOT turn off power while updating. 3. Please ensure the device is properly installed and DO NOT remove the device while updating. 4. Please ensure all current applications are terminated before proceed updating. At the bottom are 'OK' and 'Cancel' buttons.</p>
<p>2 Choose "Upgrade".</p>	 <p>The 'Philips PCDV5016 DROM5016 Upgrade to P1.7 A-01' dialog box has a blue title bar with a red close button. It features a dropdown menu showing 'PHILIPS DROM5016 P1.6 Version 0.1'. Below the menu is an 'Upgrade' button and an 'Exit' button.</p>
<p>3 Click "Yes" to confirm and wait some seconds.</p>	 <p>The 'WARNING' dialog box has a blue title bar with a red close button. It contains a yellow warning icon and the following text: 'WARNING!! PLEASE DON'T TURN OFF THE POWER! Some permanent application or software may cause unsuccessful upgrade. Please make sure to turn off all the application software before you run this firmware refresh tool. Continue ?'. At the bottom are 'Yes' and 'No' buttons.</p>
<p>4 Your drive is now upgraded. Click "OK" to exit the upgrade program. Your system will be restarted.</p>	 <p>The 'DVD Firmware Upgrade Program - Restart System' dialog box has a blue title bar with a red close button. It contains the text: 'Updating complete! System will now reboot,press OK to reboot. Please remove any diskette from bootable device (A:\) and other bootable devices.' At the bottom is an 'OK' button.</p>