


Quick Setup Guide


Unpack the machine and check the components




Read the Safety Guide first, then read this Quick Setup Guide for the correct installation procedure.

NOTE:
The USB cable is a standard accessory.


1 Remove the packing materials and install the toner cartridge



2 Load paper in the paper tray



3 Connect the power cord and turn on the machine



Printer LED Indications

Blinking: ☀ ON: ● or ● OFF: ○


	Toner Low ¹	Replace Toner	Drum End Soon ¹	Replace Drum	Drum ! ²	Paper Jam / Cover is Open ²	No Paper
Toner	☀	●	○	○	○	○	○
Drum	○	○	☀	●	☀	○	○
Paper	○	○	○	○	○	☀	●
Ready	●	○	●	●	○	○	○

¹ The yellow LED will blink in a pattern of ON for 2 seconds and then OFF for 3 seconds.

² The LED will blink ON and OFF at 0.5 second intervals.


For more indications information, please visit our service support website: <http://www.fujixeroxprinters.com/>.

4A Configuration using the CD-ROM (Windows®)



Follow the on-screen instructions until the **Connect the machine** screen appears.

NOTE:
If the Fuji Xerox screen does not appear automatically, go to **Computer**.
(For Windows® 8: click the **File Explorer** icon on the taskbar, and then go to **Computer**.)
Double-click the CD-ROM icon, and then double-click **start.exe**.



Follow the on-screen instructions to continue installation.

Finish

NOTE:
If connection is unsuccessful, repeat this step.

4B Configuration without using the CD-ROM (Windows® without CD-ROM drive or Macintosh)

Download the full driver and software package by visiting the Fuji Xerox website at <http://www.fujixeroxprinters.com/>.