1 产品外观及配件



* Micro USB输出12V，请勿给手机充电

1. X1 摄像机 × 1
2. 支架3M胶贴 × 1
3. 遥控拍照按钮 × 1
4. 遥控器胶贴 × 1
5. 车载充电器+Micro USB线

2 产品结构及按键说明





1. 电源接口
2. 工作指示灯 (红)
3. 停车监控指示灯 (蓝)
4. 复位孔
5. TF卡插口
6. 转轴
7. 胶贴支架
8. 麦克
9. 扬声器
10. 拍照按钮

3 安装步骤



1. 打开保护盖，将存储卡插入卡槽，注意正反面。完成后把保护盖盖好。



2. 把支架通过3M胶粘在后视镜前的挡风玻璃上(注意方向和位置，粘贴牢固后很难取下)。



3. 按照图例方式将USB充电线布置与车内并插入点烟器。汽车启动后，摄像机自动开启，并发出开机提示音，表示已经进入正常工作状态。

注：

- 支持最大128GBTF卡，务必选配Class 10高速卡。设备工作时请勿插拔TF卡。64GB及以上TF卡使用前请先通过APP进行格式化，否则无法识别。
- X1内置降压模块和温度保护模块，可无需接降压线直接改装接车内ACC电源，为保证车内安全我们不建议用户私自改装，需专业人士协助完成。
- X1提供的Micro USB充电器输出为12V，请勿使用此线缆为手机或其他便携式电子设备充电，以免损坏设备。
- 遥控器可粘贴在中控台、档位旁、方向盘上等位置，切勿放置在汽车安全气囊的位置。若硅胶失去粘性，用水清洗即可恢复。

4 使用说明

（1）APP下载安装

手机登陆官方网站www.ddpai.com/download.html 选择相应的IOS / android 进行下载；
iPhone用户也可以在App Store搜索“盯盯拍”进行下载。

扫码下载App

（2）手机连接摄像机

Android手机：点击盯盯拍图标启动App — 主界面点击添加摄像机 —在WiFi 列表中选择“DDPai_X1” — 输入密码1234567890连接上摄像机。

iphone手机：iphone设置 — 无线局域网 — 选择“vYou_D-DPai_X1”的WiFi — 输入密码 1234567890 — 点击盯盯拍图标启动APP。

注：

- Android手机请勿在手机设置中连接盯盯拍WiFi。
- 若修改摄像机WiFi密码后忘记密码，长按RESET按键6秒可恢复出厂设置，出厂密码为：1234567890 。

（3）视频预览、回放和下载

视频预览：手机连接摄像机成功后，点击播放图标可预览当前正在录制的画面。

视频回放：在预览界面，将播放进度条往左拖动，或在屏幕中间左右滑动，可进入回放模式，可通过缩略图的选择或时间点的选择，回放之前录制的内容。

视频下载：在回放模式下点击“剪刀”图标进入时间轴裁剪下载界面，通过拖动进度条可选择5分钟内的任意视频，直接通过WiFi下载到手机。

（4）抓拍、短视频录制和下载

抓拍、短视频录制：按下遥控器上拍照按钮可以抓拍，在视频预览界面点击“拍照关联视频”图标，即可在拍照时同步录制前后5秒共10秒钟的一段短视频。

下载：在设置中打开自动下载选项，App连上摄像机后即可自动下载照片和视频，如果关闭自动下载，可手动选择需要的内容下载，不需要的可直接在摄像机内删除。

（5）相册管理和分享

在App的相册中选择照片和视频（长按可选择多个文件），可加入收藏夹或美化照片，分享到社交网络，或直接删除。

（6）遥控器配对

购买时摄像机和遥控器默认已配对好，若无法拍照，可尝试进行配对：摄像机设置 — 遥控器配对 — 将遥控器靠近摄像机（10cm距离）— 按几次遥控器按钮完成配对。

如果按下遥控器后LED灯不亮，请更换遥控器电池，打开遥控器后盖，更换纽扣电池即可

（7）其他详细操作和设置

请访问盯盯拍网站www.ddpai.com，进入官方拍客社区交流操作设置和更多新玩法。

5 注意事项

- 为了提升用户体验，我们会定期更新APP和摄像机固件，提供更多新功能和新玩法。
- 摄像机存放温度-20℃至70℃。
- 如果电池更换不当会有爆炸危险，只能用同样类型或等效类型的电池来更换。
- 不可用刺激性的化学溶剂进行清洁，建议用微湿的纸巾或软布进行擦拭。
- 请注意保护环境卫生，勿随意丢弃，切勿将产品投掷于火中，以免发生爆炸。
- 不可尝试开启外壳或自行维修，本产品若出现故障，请致电官方客服，或联系盯盯拍微信、微博客服进行相关咨询。
- 本产品不仅限用于车辆，其他场所也可使用。

6 规格参数

（1）核心硬件

处理器：H.264硬件编码, 1080P@30fps全高清视频编码，低功耗。
图像芯片：SONY 1/2.9英寸Exmor CMOS图像传感器，超低照度。
镜头：6组玻璃镜片，1个红外滤波片；对角线140° 广角；F1.8光圈。

（2）技术参数

无线模块：内置WiFi、2.4GHz。WiFi与手机直连，2.4GHz遥控拍照。
存储：TF卡存储，最大支持128GB，卡满后自动循环录像。
视频输出：无线视频输出，支持Android/iPhone手机或平板。
G-Sensor：内置三轴加速度传感器，碰撞锁存，灵敏度通过App调节。
摄像像素：1920x1080@30fps。
拍照像素：1920x1080。
运行内存：128M。

7 联系方式

盯盯拍（深圳）技术股份有限公司
客服电话：400-163-0062
官网网址：www.ddpai.com
执行标准：GB8898-2011；GB13837-2012；GB17625.1-2012 检验合格
深圳市南山区粤海街道软件园怡化金融科技大厦12楼

微信扫描关注我们

版权所有 ©盯盯拍（深圳）技术股份有限公司 保留一切权利。
本资料仅供参考，不构成任何形式的承诺。





* 12V output, Do Not charge mobile phone

1. X1 Camera ×1
2. 3M Sticker ×1
3. Remote Snap ×1
4. Removable Sticker ×1
5. Car Power Apapter + Micro USB Cable

2 X1 Camera at a Glance





1. Micro USB Power Socket
2. Working Indicator (Red)
3. Parking mode (Blue)
4. Reset Button
5. TF Card Slot
6. Shaft
7. Plastic stent
8. Mic
9. Speaker
10. Remote Snap Button

3 Getting Started



1. Insert the TF Card into the Slot (note the direction).



2. Stick the plastic stent onto the windshield (note the position).



3. Connect the USB cable with camera and Car adapter. When the car starts up, the camera will boot up automatically with voice prompt “Hello”.

Note:

- Support up to 128GB TF Card. Class 10 is necessary. Do not plug the TF card when the Camera is working. Beforehand, please format the 64GB or above TF card through APP, or else it cannot be read.
- The Output of Micro USB is 12V, please do not charge your mobile phone.
- Please do not refit the power supply.
- You can stick the remote snap button on the Console, beside the gear box, or on the steering wheel. DO NOT put it on the position of Airbag.

4 Instructions for use

1. App Download

For Android/IOS Apps, Please search for DDPai in Google Play or App Store, download and install.

2. Connect the Camera to mobile phone

For iPhone:
iPhone Settings — WLAN — Select vyou_DDPai_X1 — Enter the Password 1234567890 to connect the camera AP— Launch DDpai App and the camera will be displayed in the camera list·

For Android:
Launch DDpai App— Click “+” to Search the camera — Select DDpai_X1 in the WiFi list — Enter the Password 1234567890 to connect camera.

Note: For Android, do not connect the camare WiFi in phone settings. If forgotten the password, press the reset button for a few seconds to restore factory settings. The initial password is 1234567890.

3. Live Preview ,playback and video clips download

Preview:When the mobile phone is connected to the Camera, click play button to preview the Real-time video.

Playback: In full-screen preview mode, drag the progress bar or slide the touch screen, and find the photo that you need by thumbnail images and playback.

Download video clips: In playback mode, click the scissors icon to launch download UI, and drag the progress bar and find the video clips to download.

4. Take a photo or record video

Click the remote snap button to capture a photo. Switch on the “10s video” option in the camera setting to record 10 seconds video (5 seconds before and after the click action). The photos and videos will be specially stored in the Camera TF Card and wait a few seconds to be transferred into your mobile phone.

5. Photo Album management and Share the photos

Check all the photos and videos in photo album. You can choose several photos to add to favorite, or delete, or share to social network.

6. Pair the remote button to camera

If the remote snap doesn’t work,press the button to check the indicator light.If the indicator light is on, please enter the Camera Setting-Advance Settings-remote controller pairing,and take the remote sanp near the camera and press the button several times to pair.
If the indicator light is not on, the battery may have run down. Please open the rear cover of the remote snap and replace a new battery cell.

7. Other settings

Enter the setting to modify the general settings. To change the camera setting, you must connect the camera and enter the camera settings. You can change the image quality, mute the mic, adjust the volume etc.

5 Attention

- Apps and Camera firmware continuously update.
- Store temperature: -20℃~70℃
- Stain on the lens would seriously reduce the image quality. Cleaning tool is very simple: the lens paper with a cloth or a fine tool, lens brush and cleaning sets. Do not use cardboard, paper towel or napkin to clean the lens.
- In case of some troubles or damage do not attempt repairing the camera by yourself. The camera must be repaired or adjusted only by specialists.
- When this product reaches its end of life, take it to a collection point designated by local authorities for the recycling of electronic equipment.

6 Specifications

1. Main hardware

CPU: 1080P@30fps/H.264 encoder
Image Sensor: Sony 1/2.9 inch Exmor CMOS Sensor
Lens: 6-glasses, 140°Wide Angle, F1.8

2. Technical Parameters

Wireless: WiFi & 2.4GHz
Storage: Class10 TF Card, up to 128GB
Video Output: Wireless video stream to mobile phone
G-Sensor: three axis acceleration sensor, collision latch, APP adjusting sensitivity.
Video pixel: 1920x1080@30fps
Camera pixel: 1920x1080
RAM: 128M

盯盯拍

X1

用户手册
User's Manual